

PRO-LINE®

SHORT COURSE 2.2"/3.0" WHEEL OFFSET GUIDE

PROTRAC ZERO OFFSET

2745-03
2740-03
2740-04
2731-01
2731-03

PROTRAC +3 3MM OFFSET

2739-03

SLASH REAR 9MM OFFSET

2746-03
2725-03
2721-02
2715-04

SLASH FRONT 13MM OFFSET

2714-04

