

PRO-LINE

D8T Front body mount relocation instructions for Bulldog body

1. Remove shock tower from truck
2. Cut out template below
3. Match up template with shock tower
4. Mark and drill holes using a 1/8" drill bit

