

Pro-Line Undertray for Slash® 4X4 3325-00

Illustration #1



1. Using Lexan scissors cut along the scribed lines and Remove the excess material from the undertray. (illustration #1)

2. Drill out the two front bumper screw holes and four rear skid plate screw holes.

3. Drill out the marked locations on the side of the undertray. Using lexan scissors or a hobby knife cut along the line this will allow the passage of the side mount during installation. (illustration #2)

Illustration #2



4. Remove the 3 front bumper screws, two front skid plate screws, and four rear skid plate screws from your slash truck. You will also need to remove the body side supports and set them to the side.

5. Lay the undertray into position and secure the front and rear using the screws previously removed.

6. To attach the side post supports you will have to push it through the side of the undertray using the slot previously cut out. Bending the upper portion of the slot will help the support attach to the chassis. Using the screws removed re-attach the side support. Upon completion your side supports should look like (illustration #3)

Illustration #3



7. Re-attach the front bumper and your ready to go. The sides of the undertray can be cut to any size depending on preference.

PRO-LINE
PROLINERACING.COM

Illustration #4

