

# PRO-LINE®

## SHORT COURSE 2.2"/3.0" WHEEL OFFSET GUIDE

### ■ PROTRAC ZERO OFFSET

# 2745-03  
# 2740-03  
# 2740-04  
# 2731-01  
# 2731-03

### ■ PROTRAC +3 3MM OFFSET

# 2739-03

### ■ SLASH REAR 9MM OFFSET

# 2746-03  
# 2725-03  
# 2721-02  
# 2715-04

### ■ SLASH FRONT 13MM OFFSET

# 2714-04

