

PRO-LINE

APPLICATION CHART 2009

RACING.COM



2/2/09

Tires

Part #	Description	Available Compounds ▲ XTR ● M2 ■ M3	Price
1139-00/01/02	Hole Shot LPR	▲ ● ■	\$32.00/34.00
1140-00/01/02	Bow-Tie LPR	▲ ● ■	\$32.00/34.00
1141-00/01/02	Crime Fighter LPR	▲ ● ■	\$32.00/34.00

Wheels

Part #	Description	Price
2699-02/04	LPR 17mm Velocity Dish (Standard Offset)	\$15.50
2700-02/04	LPR 17mm Velocity Dish (1/2" Offset)	\$15.50

Bodies

Part #	Description	Price
3213-00	Crowd Pleazer 2.0	\$33.00
3228-00	Crowd Pleazer 2.0	\$33.00
3258-00	Crowd Pleazer 2.0	\$33.00
3285-00	SHIFT	\$33.00
3287-00	SHIFT	\$33.00

PRO-LINE

1496-00	HardDrive	\$33.00
---------	-----------	---------

Accessories

6023-02/03/04	High Downforce Wing	\$16.50
6024-04	Performance Wing	\$16.50
6118-00	1:8 Low Pro Air Filter Assembly	\$33.00

Available Compounds
▲ XTR ● M2 ■ M3

Hard Packed / Blue Groove
Hard Packed / Light Dust
Medium Packed / Moist
Medium Packed / Loamy
Loamy
Clay
All-Terrain
Asphalt
Sand

TRACK CONDITIONS											
▲	●	▲	●	▲	●	▲	●	▲	●	▲	●
▲	●	▲	●	▲	●	▲	●	▲	●	▲	●
▲	●	▲	●	▲	●	▲	●	▲	●	▲	●



1139-00/01/02 Hole Shot LPR \$32.00/34.00



2699-02/03/04 Velocity Dish (Standard Offset) \$15.50



3287-00 SHIFT fits Associated RC8T \$33.00



6300-00 Metric Allen Tool Kit (2.5, 2.5 Ball, 2.0, 2.0 Ball, 1.5mm) \$75.00
6300-01 Standard Allen Tool Kit (3/32", 5/64", 1/16", .050) \$59.00



1496-00 HardDrive fits Losi 8ight T \$33.00

Gluing Instructions

MT Wheel Prep


Chrome Removal Instructions

- For best tire mounting results, remove chrome finish from the lip of wheel. Use 100 grit sand paper or remove carefully by scraping off with a sharp hobby knife.

MT Tire Gluing Instructions

- Clean bead of tire with alcohol for best adhesion.
- Place wheel into tire and pull tire beads into place. Wrap a thick rubber band around the tire close to the edge of the bead to be glued to hold tire against wheel.
- Pull back this bead of tire so that the inner bead is exposed (see figure below). Place a drop of glue on wheel and set the tire back. Repeat process around wheel until entire bead has been glued. Once the inner bead is glued, gently pull back the outer bead of tire. Place any needed glue on exposed areas and let dry.
- Repeat step 2 & 3 on other side of the tire.

Gluing Area (Inner bead)



Tire Care & Tips

- To ensure the full life of your foam inserts, do not expose to any type of moisture. Moisture will cause the foam to breakdown and tear in most cases. Vent both wheels and tires to allow dirt to escape. To do this use a leather punch or scissors and cut two diamond shaped holes on opposite ends of the tire.
- When running on loamy or soft conditions, rotate tires front to back for optimum performance.
- When running on hard-packed, blue-groove type conditions, do not rotate tires as a sharp edge on this type of surface tends to cause a skating type sensation.
- For extended rubber freshness, store tires out of sunlight and in a sealable sandwich bag.
- For bearing longevity and optimum track performance, a balanced tire is recommended, just as in full-scale racing. To do this, we recommend using some type of R/C Propeller balancer and modeling clay. Balance once the tire is mounted and glued.

TREAD PATTERN RESPONSE

